

# BailieBilt® Fender Stone Guard Instructions



**Step 1:** Lay out all parts and inspect them. You should have 2 Fender Stone Guards (one Left and one Right) and 1 bag of self-tapping screws. The panels are shipped flat except for the inner lip. They have perforations at the bend location. *(Tools shown are not included in kit.)*



**Step 2:** Tools required are a 1/4 in. drive ratchet with extension, a 5/16 in. socket, a power drill with a 90° angled head attachment and a 1/16 in. drill bit. You will also need a contrasting color Sharpie® marker. Black for light vehicles and Metallic Silver for dark vehicles works best.



**Step 3:** Slightly bend and insert each Fender Stone Guard in place as shown. Edges of the guard should match the seam edge inside the fender.



**Step 4:** While firmly holding panel in place, mark the hole locations with the Sharpie® marker.

# Fender Stone Guard Instructions - continued



**Note:** Remove Stone Guard before drilling pilot holes.

**Step 5:** Remove Fender Stone Guard and drill 1/16 in. pilot holes for the self-tapping screws. (*Stone guard is in place in photo for illustration purposes only. Damage may occur if Stone Guard is left in place during this step!*)



**Step 6:** Re-install Fender Stone Guard. Then, using the 1/4 in. ratchet and socket, install all self-tapping screws securely. (*Caution: over tightening may cause threads to strip*)